PHI 5000 Versaprobe-II Focus X-ray Photo-electron Spectroscopy



↓ ULVAC·PHI, IDC.

The very basic theory of XPS

XPS theroy Surface Analysis Ultra High Vacuum (UHV)



XPS Theory

XPS = X-ray Photo-electron Spectroscopy



XPS as a Surface Analysis technique



1. Only the generated photo-e from the top surface about 5 to 75A can have enough energy to pop out of the sample surface.

2. Minimum X-ray probe size from the Versaprobe-II system is ~10um and it makes small area analysis possible.

3. No special sample preparation is required for XPS analysis

↓ ULVAC·PHI, IDC.

Why Ultra High Vacuum

 The generated Photo-electrons are coming from the very top surface of the sample (0.5-7.5nm)

Therefore it is very surface sensitive.

- Surface Analysis = surface sensitive
- So its important to first have the UHV environment to avoid surface contamination



System component

System component overview



↓ ULVAC·PHI, INC.

X-ray Generation (1), Concept of focus X-ray



- The source Electron Beam is generated by a LaB6 filament. The emitted E-beam is then focus by Electrostatic lens and be able to scan onto the Aluminum Anode by varying the voltages on the scanning plates.
- On the Al Anode, a scanning X-ray is generated by the scanning E-beam. Then with the reflection takes
 place at the Monochromator, the scanning X-ray could be reflected and uses as the source beam onto
 the sample.

O ULVAC-PHI, INC.

X-ray Generation (2), Concept of focus X-ray

Scanning X-ray Beam Induced Secondary Electron Image



Versaprobe-II Specification < 10 µm

↓ ULVAC·PHI, INC.

Analyzer Input lens

- Purpose of Input lens The analyzer is making an angle to the sample surface (usually 45-degree)
- When photo-e(s) are generated by the X-ray and pop-out of the surface, they tends to fly all over in the provided vacuum environment.
- So to enhance the number of photo-e that can go into the Analyzer, we will need the Input lens to attract and focus the maximum number of photo-e into the Energy Analyzer



- There are 3 lens in this input lens, as function in attracting and focusing the photo-e into the optics path, then direct into the Energy Analyzer.
- The Input lens is also scanning and it is synchronize to the X-ray scanning.
- The 3 lens are named as:
 - Gauze lens
 - Scanning lens
 - Lens 2
 - Lens 3



Hemispherical Spherical Analyzer (HSA)



Outer Sphere

- By controlling the voltages on Inner Sphere (IS) and Outer Sphere (OS), we could generate a electrostatic field which act as kind of a band-pass filter. So we could set as what energies' photo-e can go travel along the Analyzer path.
- When saying different energies of the photo-e, we means the speed of the photo-e (i.e. Kinetic energies)
- The selected range of photo-e energies range will finally arrive to the detector.
- The difference in voltage between the inner & outer sphere is the Pass Energy

↓ ULVAC·PHI, INC.



Multi-Channel Detector



- The PHI-5000 Versaprobe-II system equip with a 16channel Multi-Channel Detector (MCD).
- The Multi-Channel Detector allows the system to achieve a higher sensitivity XPS spectrum.
- The 16 channels data are stored into a capacitor matrix and then convert to XPS data by appropriate Hardware protocol and Software interface.
- Now we got the whole XPS phenomena took-place and spectra is generated.

↓ ULVAC·PHI, INC.

The FIG-5 Ion gun (with floating)



-The ion gun in the Versaprobe-II system has 3 main purposes Cleaning (surface contamination) Sputtering (Depth-profiling) Charge Neutralization



Electron Neutralizer (Together with Ion Neutralization)



Traditional electron flood gun charge neutralization is not effective in neutralizing the localized positive charge created by the x-ray beam because the samples static charge interferes with the low energy electron beam.

PHI's patented* dual beam charge neutralization method uses a low energy ion beam to eliminate the samples static charge allowing the low energy electron beam to reach the sample and neutralize the localized positive charge created by the x-ray beam.



PHI typical electron source energy ~ 1 eV

PHI typical ion source energy ~ 5 to 10 eV

↓ ULVAC·PHI, INC.

Chemical Damage with Traditional Sputtering

15 keV Ga



□ Molecular Dynamics provide

insights

□ Energy cascade produced

deep into the sample

Energy cascade promotes

chemical damage

□ Sputtering only from the

surface

Chemical damage remains

 C_{60} bombardment calculations, Zbigniew Postawa; Enhancement of Sputtering Yields due to C_{60} vs. Ga Bombardment of Ag{111} as Explored by Molecular Dynamics Simulations, Z. Postawa, B. Czerwinski, M. Szewczyk, E. J. Smiley, N. Winograd and B. J. Garrison, Anal. Chem.y, 75, 4402-4407 (2003); Microscopic insights into the sputtering of Ag{111} induced by C_{60} and Ga Bombardment, *ibid.*, J. Phys. Chem. B108, 7831 (2004).



Sputtering with C₆₀ lons



 C₆₀ molecule collapses on impact distributing its initial acceleration energy over 60 C atoms:

- □ Shallow penetration depth
- Efficient removal of material
- □ Thin damage layer
- Practical cleaning and depth profiling of organic/polymer materials

So what can the PHI 5000 Versaprobe-II system do?

Real-life examples...

↓ ULVAC·PHI, IDC.

Example for PET analysis (Showing Charge Neutralization)





Scanning X-ray Beam for Secondary Electron Images of all Conducting and Insulating Samples

Secondary electron image quickly locates contamination

and features for XPS analysis

Accurate location of 10 micron features



↓ ULVAC·PHI, INC.

User selects Analysis areas for Scanning X-ray Beam using Secondary Electron Images

Chemical identification of clean polymer and contaminant with XPS analysis



Scanning X-ray Beam Produces User Defined Areas for XPS Elemental and Chemical State Maps

XPS maps provided spatial distribution information and identified areas for additional micro-area spectroscopy

F 1s Map C 1s Map 50 µm 50 µm 100 µm 100 µm SXI Sample F (red) + C (Green) features not associated with fluorine. What are 50 µm 100 µm they? Mapping area 100 µm

100 µm

O ULVAC-PHI, INC.

Scanning X-ray Beam Located on Micro-defects for Elemental and Chemical State Identification

Secondary electron images, maps, and micro-area spectroscopy identified a contaminant that would go undetected in a non-microprobe system



Typical XPS Applications

Semiconductor Devices

- Defect particles
- Etch residue
- Shorting problems
- Contact contamination
- Multilayer thin film analysis

Display Devices

- Defect particles
- Shorting problems
- Inter-diffusion
- Cleaning residue

Magnetic Storage Media

- Surface Particles
- Inter-diffusion of layers
- Pinhole defects
- Surface corrosion
- Magnetic head defects

Metals, Glass and Ceramics

- Grain boundary segregation
- Cleaning failures
- Precipitates

PHI 5000 Versaprobe-II Focus X-ray Photo-electron Spectroscopy



↓ ULVAC·PHI, IDC.